Break out if the strap touches
the side of the cam mounting plate
(this happens when the column has a larger diameter)

FKM   Column

Detail "B"

Turn clockwise

Pulled

Fixed

B

Anti skid points

Adjustment thumbscrew
To level out the flat panel

Max. Load 60kg
Suitable for L&S 3 + 5 mounts

Locking the mounting cams

NOTE: All dimensions are ±..., in mm and subject to change

Tighten with Socket Wrench
Size: 8 mm
Maximum Torque: 4 Nm

Delivered strap:
1600 mm (FKM-2050) / 3200 mm (FKM-5080)
The Strap can be cut after attachment
of the FKM to the column

MANUAL
FKM-2050 & FKM-5080

Column Mount

Dimensions are indications, not to be used for any preparations. No rights can be derived from the above dimensions.