







PWM-450 installatie handleiding


installation guide

installationhandbuch


guide d'installation







NOTE: All dimensions are \pm ..., in mm and subject to change

<p>© COPYRIGHT AUDIPACK This print and the information shown thereon, is the property of AUDIPACK. It may not be delivered to others nor reproduced for general circulation without the written consent of the AUDIPACK engineering department.</p>	 <p>AUDIPACK[®]</p> <p>AUDIPACK Industriestraat 2-4 2751 GT Moerkapelle the Netherlands</p> <p>Tel: +31(0)795931671 Fax: +31(0)795933115 www.audipack.com</p>
<p>DRILLING PATTERN</p>	

