

*Plug for  
Linak Control Boxes*

460359



## Plug behaviour

*Opmerking: De control box moet software versie 1.53 of later hebben.*

Note: the control box must have software version 1.53 (latest version)

### EN

1. Set the desired maximum travel / position of the lift.
2. Then insert the blue plug in channel A1 or A2 of the CBD6S control box.

The travel will be set at this particular position. The plug must stay inserted in the CBD6S. Removing the plug will discard the set travel.

### NL

1. Stel de gewenste slag in van de lift.
2. Steek dan de blauwe plug in aansluiting A1 of A2 van de control box. Zolang deze in de control box is gestoken, wordt de beweging tot deze hoogte begrensd.



*Figuur 1 – Control box without plug / Control box zonder plug*



*Figuur 2 - Control box with plug / Control box met plug*